



NOTE:
Fixing into studs at maximum 600mm centres.
Type 17 stainless steel 65mm roofing screws.

H3.1 200mm long packers
with separation layer over

NOTE:
Builder to install 140x45 vertical
blocking between dwangs

Building wrap or Rigid Air
Barrier installed as per
manufacturers specification